| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | TV | | TV/Radio / |
| | Radio | | + Shift + TV/Radio / Program |
| | Subtitle | | Subtitle / EQ |
| | ALT | | Smart / List |
| | ARC | | Display / Media |
| | TV Guide | | Guide / EPG / -/-- |
| | Mute | | Mute / Dimmer |
| | Language | | Audio / Lang I/II |
| | PG | | Sound / Title |
| | Info | | Info / Angle |
| | Exit | | Exit / Cancel / Clear |
| | Up | | Up |
| | Left | | Left |
| | OK | | OK |
| | Right | | Right |
| | Down | | Down |

| Original | | Replacement | |
|---|---|---|---|
| | P+ | | CH+ / Page+ |
| | V+ | | Vol+ |
| | P- | | CH- / Page- |
| | V- | | Vol- |
| | Red | | Red / Netflix / Search |
| | White | | Fav / Marker / PC |
| | Green | | Green / APP / Repeat |
| | Blue | | Blue / Prime Video / Random |
| | Yellow | | Yellow / YouTube / Repeat |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |

| Original | | Replacement | |
|---|---|---|---|
| 9 wxyz | 9 | BLUETOOTH 9 | 9 |
| MENU | Menu | HOME MENU | Menu / Home |
| HELP | Help | GOTO TEXT | Text / Goto |
| 0 _ | 0 | HDMI - SAT 0 | 0 |

| Original | Replacement |
|---|---|
| | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | TV | | TV/Radio / |
| | Radio | SHIFT + | PROGRAM TV/RADIO Shift + TV/Radio / Program |
| | Subtitle | | EQ SUBTITLE Subtitle / EQ |
| | ALT | | LIST SMART Smart / List |
| | ARC | | MEDIA DISPLAY Display / Media |
| | TV Guide | | -/-- GUIDE EPG Guide / EPG / -/-- |
| | Mute | | DIMMER MUTE Mute / Dimmer |
| | Language | | LANG I/II AUDIO Audio / Lang I/II |
| | PG | | TITLE SOUND Sound / Title |
| | Info | | ANGLE INFO Info / Angle |
| | Exit | | CLEAR EXIT CANCEL Exit / Cancel / Clear |
| | Up | | Up |
| | Left | | Left |
| | OK | | OK |
| | Right | | Right |
| | Down | | Down |

| Original | | Replacement | |
|---|---|---|---|
| | P+ | | CH PAGE CH+ / Page+ |
| | V+ | | VOL Vol+ |
| | P- | | CH PAGE CH- / Page- |
| | V- | | VOL Vol- |
| | Red | | NETFLIX SEARCH Red / Netflix / Search |
| | White | | PC FAV MARKER Fav / Marker / PC |
| | Green | | APP REPEAT Green / APP / Repeat |
| | Blue | | Prime Video RANDOM Blue / Prime Video / Random |
| | Yellow | | YouTube REPEAT A-B Yellow / YouTube / Repeat |
| | 1 | | TV 1 1 |
| | 2 | | DVD 2 2 |
| | 3 | | CD - STB 3 3 |
| | 4 | | VIDEO 4 4 |
| | 5 | | TAPE 5 5 |
| | 6 | | TUNER 6 6 |
| | 7 | | AUX - HDD 7 7 |
| | 8 | | USB 8 8 |

| Original | | Replacement | |
|---|---|---|---|
| 9 wxyz | 9 | BLUETOOTH 9 | 9 |
| MENU | Menu | HOME MENU | Menu / Home |
| HELP | Help | GOTO TEXT | Text / Goto |
| 0 _ | 0 | HDMI - SAT 0 | 0 |

| Original | Replacement |
|---|---|
| | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | TV | | TV/Radio / |
| | Radio | SHIFT + | Shift + TV/Radio / Program |
| | Subtitle | | Subtitle / EQ |
| | ALT | | Smart / List |
| | ARC | | Display / Media |
| | TV Guide | | Guide / EPG / -/-- |
| | Mute | | Mute / Dimmer |
| | Language | | Audio / Lang I/II |
| | PG | | Sound / Title |
| | Info | | Info / Angle |
| | Exit | | Exit / Cancel / Clear |
| | Up | | Up |
| | Left | | Left |
| | OK | | OK |
| | Right | | Right |
| | Down | | Down |

| Original | | Replacement | |
|---|---|---|---|
| | P+ | | CH+ / Page+ |
| | V+ | | Vol+ |
| | P- | | CH- / Page- |
| | V- | | Vol- |
| | Red | | Red / Netflix / Search |
| | White | | Fav / Marker / PC |
| | Green | | Green / APP / Repeat |
| | Blue | | Blue / Prime Video / Random |
| | Yellow | | Yellow / YouTube / Repeat |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |

| Original | | Replacement | |
|---|---|---|---|
| 9 wxyz | 9 | BLUETOOTH 9 | 9 |
| MENU | Menu | HOME MENU | Menu / Home |
| HELP | Help | GOTO TEXT | Text / Goto |
| 0 _ | 0 | HDMI - SAT 0 | 0 |

| Original | Replacement |
|---|---|
| | |

| Original | Replacement |
|---|---|
| Power | Power |
| TV | TV/Radio / |
| Radio | Shift + TV/Radio / Program |
| Subtitle | Subtitle / EQ |
| ALT | Smart / List |
| ARC | Display / Media |
| TV Guide | Guide / EPG / -/-- |
| Mute | Mute / Dimmer |
| Language | Audio / Lang I/II |
| PG | Sound / Title |
| Info | Info / Angle |
| Exit | Exit / Cancel / Clear |
| Up | Up |
| Left | Left |
| OK | OK |
| Right | Right |
| Down | Down |

| Original | Replacement |
|---|---|
| P+ | CH+ / Page+ |
| V+ | Vol+ |
| P- | CH- / Page- |
| V- | Vol- |
| Red | Red / Netflix / Search |
| White | Fav / Marker / PC |
| Green | Green / APP / Repeat |
| Blue | Blue / Prime Video / Random |
| Yellow | Yellow / YouTube / Repeat |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |

| Original | | Replacement | |
|---|---|---|---|
| 9 wxyz | 9 | BLUETOOTH 9 | 9 |
| MENU | Menu | HOME MENU | Menu / Home |
| HELP | Help | GOTO TEXT | Text / Goto |
| 0 _ | 0 | HDMI - SAT 0 | 0 |

| Original | Replacement |
|---|---|
| | |