Original		Replacement	
INPUT	Input	RDS AV INPUT	AV / Input / RDS
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
CH.LIST	CH. List	SHIFT + LIST SMART	Shift + Smart / List
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat

Original		Replacement	
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	[=]	HOME MENU	Menu / Home
	Up		Up
▶/II	Play	SLOW	Play / Slow
▶/II	Pause	STEP - FREEZE	Pause / Step / Freeze
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
←	←	RETURN BACK	Back / Return
+ VOL	Vol +	+ VOL	Vol +
0	0	PC FAV MARKER	Fav / Marker / PC
CH	CH+	+ CH PAGE	CH+ / Page+
VOL —	Vol -	VOL —	Vol -
	Smart	LIST SMART	Smart / List
CH	CH-	CH PAGE —	CH- / Page-

Original		Replacement		Original	Replacement
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		
	Mute	DIMMER MUTE	Mute / Dimmer		
INFO	Info	ANGLE INFO	Info / Angle		
P.MODE	P. Mode	FORMAT PICTURE	Picture / Format		
MEDIA	Media	MEDIA DISPLAY	Display / Media		
TEXT	Text	GOTO TEXT	Text / Goto		
NETFLIX	Netflix	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /		
prime video	prime video	SHIFT + Prime Video RANDOM	Shift + Blue / Prime		
YouTube	YouTube	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /		
Google Play	Google Play	PROGRAM TV/ RADIO	TV/ Radio /		
Music	Music	LANG I/II AUDIO	Audio / Lang I/II		
:::	:::	TOP MENU D.MENU	D. Menu / Top		