Original		Replacement	
	Power		Power
		FORMAT PICTURE	Picture / Format
BACK	Back	RETURN BACK	Back / Return
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
	Left		Left
OK	Ok	OK	OK
	Right		Right
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
EXIT	Stop	HOLD	Stop / Hold
SMART TV	Smart Tv	LIST SMART	Smart / List
	Skip Prev.	PRESET-	I<< / Preset-
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Skip Next	PRESET+	>>I / Preset+
CH	Ch+	CH PAGE	CH+ / Page+

Original		Replacement	
VOL	Vol-	VOL	Vol-
VOL	Vol+	VOL	Vol+
CH	Ch-	CH PAGE	CH- / Page-
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
LANG	Blue/○○/Lang.	Prime Video RANDOM	Blue / Prime Video / Random
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
REC	Rec	REC MODE	Rec / Rec Mode
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
OPTION	Option	OPT-TOOLS SETUP	Setup / OPT /
SUBT	Subt.	EQ SUBTITLE	Subtitle / EQ
IPTV	IPTV	MEDIA DISPLAY	Display / Media
ECO SEARCH	Eco / Search	PC FAV MARKER	Fav / Marker / PC
GUIDE POPUP	Guide-Popup	-/-- GUIDE EPG	Guide / EPG / -/--
CH.LIST	Ch.List	SHIFT + LIST SMART	Shift + Smart / List
INFO	Info	ANGLE INFO	Info / Angle

Original		Replacement	
1	1	TV 1	1
2 ABC	2	DVD 2	2
3 DEF	3	CD - STB 3	3
4 GHI	4	VIDEO 4	4
5 JKL	5	TAPE 5	5
6 MNO	6	TUNER 6	6
7 PQRS	7	AUX - HDD 7	7
8 TUV	8	USB 8	8
9 WXYZ	9	BLUETOOTH 9	9
DISC MENU	Disc Menu	TOP MENU D.MENU	D.Menu / Top
0	0	HDMI - SAT 0	0
TEXT MEDIA CENTER	Text / Media	GOTO TEXT	Text / Goto
SOUND	Sound	TITLE SOUND	Sound / Title
	↑↓→←	SIZE ZOOM	Zoom / Size
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /

Original	Replacement

Original		Replacement	
	Power		Power
	(•♪)	PROGRAM TV/RADIO	TV/Radio /
BACK	Back	RETURN BACK	Back / Return
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
	Left		Left
OK	Ok	OK	OK
	Right		Right
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
EXIT	Stop	HOLD	Stop / Hold
SMART TV	Smart Tv	LIST SMART	Smart / List
	Skip Prev.	PRESET-	I<< / Preset-
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Skip Next	PRESET+	>>I / Preset+
CH	Ch+	CH PAGE	CH+ / Page+

Original		Replacement	
VOL	Vol-	VOL	Vol-
VOL	Vol+	VOL	Vol+
CH	Ch-	CH PAGE	CH- / Page-
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
LANG	Blue/○○/Lang.	Prime Video RANDOM	Blue / Prime Video / Random
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
REC	Rec	REC MODE	Rec / Rec Mode
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
OPTION	Option	OPT-TOOLS SETUP	Setup / OPT /
SUBT	Subt.	EQ SUBTITLE	Subtitle / EQ
IPTV	Iptv	MEDIA DISPLAY	Display / Media
ECO SEARCH	Eco/Search	PC FAV MARKER	Fav / Marker / PC
GUIDE POPUP	Guide/ Popup	-/-- GUIDE EPG	Guide / EPG / -/--
CH.LIST	Ch.List	SHIFT + LIST SMART	Shift + Smart / List
INFO	Info	ANGLE INFO	Info / Angle

Original		Replacement	
1	1	TV 1	1
2 ABC	2	DVD 2	2
3 DEF	3	CD - STB 3	3
4 GHI	4	VIDEO 4	4
5 JKL	5	TAPE 5	5
6 MNO	6	TUNER 6	6
7 PQRS	7	AUX - HDD 7	7
8 TUV	8	USB 8	8
9 WXYZ	9	BLUETOOTH 9	9
DISC MENU	Disc Menu	TOP MENU D.MENU	D.Menu / Top
0	0	HDMI - SAT 0	0
TEXT	Text/ Media	GOTO TEXT	Text / Goto
SOUND	Sound	TITLE SOUND	Sound / Title
	▬↑↓→←	SIZE ZOOM	Zoom / Size
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /

Original	Replacement