Original	Replacement
Standby	Power
Standby Tv	Shift + Power
Tv/Video	TV/R
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
10	Guide
+10	Pre Ch
Repeat	Text
A-B RPT	Shift + Text

Original	Replacement
Sleep	Sleep
Dimmer	D. Menu
Surround	Shift + Dual
Enter	Ok
Up/PTY Search	Up
Down/TA/News/Inf	Down
Right/PTY+	Right
Left/PTY-	Left
Top Menu/PG	Menu
Set Up	Smart
Setting	Options
Menu/PL	Info
RDS/FL	3D
On SCreen	Format
Audio Vol+	Vol +
Audio Vol-	Vol -
Level+	Ch +

Original		Replacement	
	Level-	CH –	Ch -
TV CHANNEL	Tv Chanel+	SHIFT + CH +	Shift + Ch +
	Tv Chanel-	SHIFT + CH –	Shift + Ch -
	Tv Vol+	SHIFT + VOL +	Shift + Vol +
AUDIO VOL TV VOL	Tv Vol-	SHIFT + VOL –	Shift + Vol -
MUTING	Muting	MUTE	Mute
DVD/CD	DVD/CD Play	PLAY MODE ▶	Play
MEMORY	Stop/Memory	■	Stop
FM MODE	Pause/FM Mode	II	Pause
RETURN	Recall	RETURN BACK	Back
RETURN	Return	SHIFT + RETURN BACK	Shift + Back
JNING	>>I/Tuning+	>>I	>>I
TUNIN	I<</Tuning-	I<<	I<<
LOW	>>/Slow+	>>	>>
SLOV	<</Slow-	<<	<<
FM/AM	FM/AM	A	Red
TV SOUND	Tv Sound	B	Green

Original		Replacement	
ZOOM SUBTITLE	Subtitle	AD SUBT	Subt
ANGLE AUDIO	Audio	SOUND DUAL	Dual
ZOOM SUBTITLE	Zoom	ZOOM ⏏	Eject
TITLE/ GROUP	Title/group	DISC NAV LIST	List
PLAY MODE	Play Mode	SHIFT + PLAY MODE ▶	Shift + Play
ANGLE AUDIO	Angle	TIMER AV	AV
SCAN MODE VFP	VFP/Scan Mode	APP MEDIA	Media
SPK-LEVEL	SKP-Level	C	Yellow
CANCEL	Cancel	CLEAR EXIT	Exit
BASS/ TREBLE	Bass/Treble	D	Blue