Original		Replacement	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	Text	GOTO TEXT	Text / Goto

Original		Replacement	
INDEX P.MODE / OK	P.Mode / OK	LIST SMART	Smart / List
INDEX P.MODE / OK	Index	SLOW	Play / Slow
INDEX P.MODE / OK	P.Mode / OK	FORMAT PICTURE	Picture / Format
AV	AV	RDS AV INPUT	AV / Input / RDS
P^	Up / P+		Up
P^	Up / P+	+ CH PAGE	CH+ / Page+
MENU	Menu	HOME MENU	Menu / Home
MENU	Menu	OK	OK
HOLD	Left / Vol-	VOL −	Vol-
HOLD	Left / Vol-		Left
HOLD	Hold	HOLD	Stop / Hold
SUB PAGE	Right / Vol+		Right
SUB PAGE	Right / Vol+	+ VOL	Vol+
SUB PAGE	Sub Page	EQ SUBTITLE	Subtitle / EQ
P∨	Down / P-		Down
P∨	Down / P-	CH PAGE −	CH- / Page-
	<<	TUNE-	<< / Tune-

Original		Replacement	
	Rec	REC MODE	Rec / Rec Mode
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
REVEAL	Reveal	STEP - FREEZE	Pause / Step / Freeze
REVEAL	i	ANGLE INFO	Info / Angle
SIZE	Size	TUNE+	>> / Tune+
SIZE	Sleep / Timer	TIMER SLEEP	Sleep / Timer
SIZE	Size	SIZE ZOOM	Zoom / Size

Original	Replacement

Original		Replacement	
	Vol-		Vol-
	Vol-		Left
	Vol+		Vol+
	Vol+		Right
	Up		Up
	Up		CH+ / Page+
	<<		<< / Tune-
	Play		Play / Slow
	>>		>> / Tune+
	Down		Down
	Down		CH- / Page-
	Stop		Stop / Hold
	Power DVD		Power

Original	Replacement

Original		Replacement	
	Vol-		Vol-
	Vol-		Left
	Vol+		Right
	Vol+		Vol+
	Up		Up
	Up		CH+ / Page+
	<<		<< / Tune-
	Play		Play / Slow
	>>		>> / Tune+
	Down		Down
	Down		CH- / Page-
	Rec		Rec / Rec Mode
	Stop		Stop / Hold
	Power VCR		Power

Original	Replacement