Original		Replacement	
	Power		Power
OPEN/CLOSE	Open/Close	ZOOM	Eject
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CLEAR	Clear	CLEAR EXIT	Exit
REPEAT	Repeat	REPEAT TEXT	Text
DISC MENU	Menu Disc	TOP MENU MENU	Menu
INFO/MENU	Menu/Info	DISPLAY INFO	Info
HOME	Home	HOME SMART	Smart

Original		Replacement	
TITLE/POPUP	Title/popup	APP MEDIA	Media
BACK	Back	RETURN BACK	Back
ENTER	Enter	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Play	PLAY MODE	Play
	Stop		Stop
	Pause		Pause
	<<		<<
	>>		>>
	I<<		I<<
	>>I		>>I
SUBTITLE	Subtitle	AD SUBT	Subt
R	Red	A	Red
G	Green	B	Green

Original		Replacement	
Y	Yellow	C	Yellow
B	Blue	D	Blue
AUDIO	Audio	SOUND DUAL	Dual
*	*	SETTINGS OPT	Options
⏻	Power Tv	SHIFT + ⏻	Shift + Power
VOL+	Vol+ Tv	+ VOL	Vol +
VOL−	Vol- Tv	VOL −	Vol -
PR/CH^	PR/CH+ Tv	+ CH	Ch +
PR/CH~	PR/CH- Tv	CH −	Ch -
AV/INPUT	AV Input Tv	TIMER AV	AV
MUTE	Mute Tv	MUTE	Mute

Original	Replacement