Original		Replacement	
POWER	Power		Power
OPEN/CLOSE	Open/Close	ZOOM	Eject
BAND	Band	B	Green
DVD	DVD	C	Yellow
AUX	AUX	A	Red
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
SLEEP	Sleep	PROG SLEEP	Sleep
XTS	XTS	DISC NAV LIST	List

Original		Replacement	
XTS pro	XTS Pro	GUIDE	Guide
SUBTITLE	[…]/Subtitle	AD SUBT	Subt
RETURN	Return	RETURN BACK	Back
AUDIO	Audio	SOUND DUAL	Dual
SOUND	Sound	SHIFT + SOUND DUAL	Shift + Dual
MARKER	Marker	HOME SMART	Smart
SEARCH	Search	SHIFT + SEARCH TV/R	Shift + TV/R
SETUP	Setup	SETTINGS OPT	Options
DISP./INPUT	Disp.	DISPLAY INFO	Info
MENU	Menu	TOP MENU MENU	Menu
TITLE	Title	SEARCH TV/R	TV/R
PRESET/CH	Up/Preset+		Up
	Down/Preset-		Down
TUN.+	Right/Tun+		Right
TUN.–	Left/Tun-		Left
ENTER	Enter	OK	Ok
VOLUME	Vol+	+ VOL	Vol +

Original		Replacement	
	Vol-	VOL –	Vol -
MUTE	Mute	MUTE	Mute
– SCAN	<<</Scan-	<<	<<
SCAN +	>>/Scan+	>>	>>
PLAY	Play	PLAY MODE	Play
– SLOW	<I/Slow-	CH –	Ch -
SLOW +	I>/Slow+	+ CH	Ch +
PAUSE/STEP	Pause/Step	II	Pause
– SKIP	I<<</Skip-	I<<	I<<
SKIP +	>>I/Skip+	>>I	>>I
STOP	Stop	■	Stop
CLEAR	Clear	CLEAR EXIT	Exit
PROG./MEMO	Prog/Memo	SHIFT + PROG SLEEP	Shift + Sleep
REPEAT	Repeat	REPEAT TEXT	Text
REPEAT A-B	Repeat A-B	ECO 3D	3D
ZOOM	Zoom	SHIFT + ZOOM ⏏	Shift + Eject
DIMMER	Dimmer	APP MEDIA	Media

Original		Replacement	
RDS RESOLUTION	RDS/Resolution	PICTURE FORMAT	Format
PTY	PTY	E-MANUAL D.MENU	D. Menu
D.INPUT	D.Input	FAV PRE-CH	Pre Ch

Original		Replacement	
POWER	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
PRESET/CH	Up		Up
	Down		Down
PRESET/CH	CH+	CH	Ch +
	CH-	CH	Ch -
DISP./INPUT	Input	TIMER AV	AV
VOLUME	Vol+	VOL	Vol +

Original		Replacement	
	Vol-	VOL	Vol -
MUTE	Mute	MUTE	Mute