Mandis shop

COV30849801

Original		Replacement	
POWER	Power		Power
EQ	EQ	EQ SUBTITLE	Subtitle / EQ
LG EQ	LG EQ	LANG I/II AUDIO	Audio / Lang I/II
OPEN/ CLOSE	Open/Close	SURROUND	Eject / Surround
PRESET/FOLDER	Preset/Folder+	+ CH PAGE	CH+ / Page+
FUNCTION	Function	LIST SMART	Smart / List
VOLUME	Vol+	+ VOL	Vol+
	Preset/Folder-	CH PAGE –	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Vol-	VOL –	Vol-
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
REPEAT	Repeat		Up
INFO	Info	ANGLE INFO	Info / Angle
	<< / I<< / Tun-	TUNE-	<< / Tune-
	<< / I<< / Tun-	PRESET-	I<< / Preset-
	<< / I<< / Tun-		Left

Original		Replacement	
	Stop	HOLD	Stop / Hold
	Stop	OK	OK
	>> / >>I /	TUNE+	>> / Tune+
	>> / >>I /	PRESET+	>>I / Preset+
	>> / >>I /		Right
PROGRAM /MEMO	Program/Memo	PROGRAM TV/ RADIO	TV/Radio /
▶/II	Play/Pause	SLOW	Play / Slow
▶/II	Play/Pause	STEP - FREEZE	Pause / Step / Freeze
▶/II	Play/Pause		Down
REC	Rec	REC MODE	Rec / Rec Mode
CLOCK	Clock	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
TIME	Time	HOME MENU	Menu / Home
SET/RDS	Set/RDS	TOP MENU D.MENU	D.Menu / Top
PTY	PTY	OPT-TOOLS SETUP	Setup / OPT /

https://all-remote-controls.co.uk/en/LG/1063974-94670-replacement-remote-control-for-LG-COV30849801.html