Mandis shop

6711R1P013D

Original		Replacement	
	Power		Power
	Eject		Eject / Surround
	Clear		Exit / Cancel / Clear
	Up		Up
	Left		Left
	Right		Right
	OK/CLK/CNT		OK
	Down		Down
	[i]		Info / Angle
	<<		<< / Tune-
	Pause/Still		Pause / Step / Freeze
	Play		Play / Slow
	>>		>> / Tune+
	Rec/QSR		Rec / Rec Mode
	Stop		Stop / Hold
	1		1
	2		2

Original		Replacement	
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	TV/VCR		TV/Radio /
	0		0
	CM Skip		Setup / OPT /
	AV		AV / Input / RDS
	C.Look		Smart / List
	VISS		Guide / EPG / -/--

https://all-remote-controls.co.uk/en/LG/1067620-4805-replacement-remote-control-for-LG-6711R1P013D.html