Original		Replacement	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
POWER	Power		Power
CBL/SAT	CBL/SAT	HDMI - SAT 0	0
DVD	DVD	DVD 2	2
Blu-ray	Blu-ray	TAPE 5	5
GAME	GAME	PC FAV MARKER	Fav / Marker / PC
AUX	AUX	AUX - HDD 7	7
MEDIA PLAYER	MEDIA PLAYER	MEDIA DISPLAY	Display / Media
TV AUDIO	TV AUDIO	TV 1	1
8K	8K	VIDEO 4	4
TUNER	TUNER	TUNER 6	6
USB	USB	USB 8	8
CD	CD	CD - STB 3	3
Bluetooth	Bluetooth	BLUETOOTH 9	9
	Heos	LIST SMART	Smart / List
PHONO	PHONO	RDS AV INPUT	AV / Input / RDS
INTERNET RADIO	INTERNET RADIO	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement	
CH / PAGE	CH/Page+	+ CH PAGE	CH+ / Page+
ECO	ECO	HOME MENU	Menu / Home
VOLUME	Volume+	+ VOL	Vol+
CH / PAGE	CH/Page-	CH PAGE –	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOLUME	Volume-	VOL –	Vol-
INFO	Info	ANGLE INFO	Info / Angle
OPTION	Option	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
TUNE –	I<< / Tune-	TUNE-	<< / Tune-
TUNE –	I<< / Tune-	PRESET-	I<< / Preset-

RADIO

https://all-remote-controls.co.uk/en/Marantz/1062734-93675-replacement-remote-control-for-Marantz-RC042SR-30701028300AM.html

Original	Replacement
Play/Pause	Play / Slow
Play/Pause	Pause / Step / Freeze
>>I / Tune+	>>I / Preset+
>>I / Tune+	>> / Tune+
Smart Select 1	Shift + Red / Netflix /
Smart Select 2	Shift + Green / APP /
Smart Select 3	Shift + Yellow / YouTube /
Smart Select 4	Shift + Blue / Prime
Sound Mode Movie / Green	Green / APP / Repeat
Sound Mode Music / Red	Red / Netflix / Search
Sound Mode Game / Blue	Blue / Prime Video / Random
Sound Mode Pure / Yellow	Yellow / YouTube / Repeat

Original	Replacement

Original		Replacement	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
POWER	Power		Power
CBL/SAT	CBL/SAT	HDMI - SAT 0	0
DVD	DVD	DVD 2	2
Blu-ray	Blu-ray	TAPE 5	5
GAME	GAME	PC FAV MARKER	Fav / Marker / PC
AUX	AUX	AUX - HDD 7	7
MEDIA PLAYER	MEDIA PLAYER	MEDIA DISPLAY	Display / Media
TV AUDIO	TV AUDIO	TV 1	1
8K	8K	VIDEO 4	4
TUNER	TUNER	TUNER 6	6
USB	USB	USB 8	8
CD	CD	CD - STB 3	3
Bluetooth	Bluetooth	BLUETOOTH 9	9
	Heos	LIST SMART	Smart / List
PHONO	PHONO	RDS AV INPUT	AV / Input / RDS
INTERNET RADIO	INTERNET RADIO	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement	
CH / PAGE	CH/Page+	+ CH PAGE	CH+ / Page+
VOLUME	Volume+	+ VOL	Vol+
CH / PAGE	CH/Page-	CH PAGE –	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOLUME	Volume-	VOL –	Vol-
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
TUNE –	I<< / Tune-	PRESET-	I<< / Preset-
TUNE –	I<< / Tune-	TUNE-	<< / Tune-
►/II	Play / Pause	SLOW	Play / Slow
►/II	Play / Pause	STEP - FREEZE II	Pause / Step / Freeze
TUNE +	>>I / Tune+	TUNE+	>> / Tune+
TUNE +	>>I / Tune+	PRESET+	>>I / Preset+

RADIO

Original	Replacement
1 Smart Select 1	NETFLIX SEARCH — Red / Netflix / Search
2 Smart Select 2	APP REPEAT — Green / APP / Repeat
3 Smart Select 3	YouTube REPEAT A-B — Yellow / YouTube / Repeat
4 Smart Select 4	Prime Video RANDOM — Blue / Prime Video / Random

Original	Replacement