Original	Replacement
Power	Power
CBL/SAT	Shift + 0
DVD	Shift + 2
TV/Audio	TV/Radio /
Blu-ray	Shift + 1
AUX1	Shift + 7
Tuner	Shift + 6
Bluetooth	Shift + 9
Game	Shift + 5
AUX2	AV / Input / RDS
Phono	Audio / Lang I/II
iPod/USB	Guide / EPG / -/--
Media Player	Display / Media
CD	Shift + 3
Online Music	Sound / Title
Internet/Radio	Shift + TV/Radio / Program
CH+	CH+ / Page+

Original	Replacement
Vol+	Vol+
CH-	CH- / Page-
Sleep	Sleep / Timer
Mute	Mute / Dimmer
Vol-	Vol-
Info	Info / Angle
Up	Up
Option	Shift + Setup / OPT / Tools
Left	Left
Enter	OK
Right	Right
Back	Back / Return
Down	Down
Setup	Setup / OPT /
Home	Menu / Home
Stop	Stop / Hold
Pause	Pause / Step / Freeze

Original	Replacement
Play	Play / Slow
I<<</Tune-	I<< / Preset-
>>I/Tune+	>>I / Preset+
<<	<< / Tune-
>>	>> / Tune+
Smart Select 1	Shift + Red / Netflix /
Smart Select 2	Shift + Green / APP /
Smart Select 3	Shift + Yellow / YouTube /
Smart Select 4	Shift + Blue / Prime
Green	Green / APP / Repeat
Red	Red / Netflix / Search
Blue	Blue / Prime Video / Random
Yellow	Yellow / YouTube / Repeat
1	1
2	2
3	3
4	4

Original	Replacement
5	5
6	6
7	7
8	8
9	9
0	0

Original	Replacement
Power	Power
CBL/SAT	Setup / OPT /
DVD	Shift + 2
TV/Audio	TV/Radio /
Blu-ray	AV / Input / RDS
AUX1	Picture / Format
Tuner	Shift + 6
Bluetooth	Shift + 9
Game	Shift + Setup / OPT / Tools
AUX2	Subtitle / EQ
Phono	Audio / Lang I/II
iPod/USB	Guide / EPG / -/--
Media Player	Display / Media
CD	Shift + 3
Online Music	Shift + Fav / Marker / PC
Internet/Radio	Shift + TV/Radio / Program
CH+	CH+ / Page+

Original	Replacement
Vol+	Vol+
CH-	CH- / Page-
Sleep	Sleep / Timer
Mute	Mute / Dimmer
Vol-	Vol-
Up	Up
Left	Left
Enter	Fav / Marker / PC
Right	Right
Back	Back / Return
Down	Down
Home	Menu / Home
Stop	Stop / Hold
Pause	Pause / Step / Freeze
Play	Play / Slow
I<<</Tune-	I<< / Preset-
>>I/Tune-	>>I / Preset+

Original		Replacement		Original	Replacement
<<	<<	TUNE-	<< / Tune-		
>>	>>	TUNE+	>> / Tune+		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
ENTER	Enter	OK	OK		