Original	Replacement	Original	Replacement
POWER	Power	9 wxyz	9
←○	SHIFT + LIST SMART Shift + Smart / List	TV	TV/ Radio /
☼*/ Ö	SHIFT + MEDIA DISPLAY Shift + Display / Media	0	0
☼²/ ♀	SHIFT + NETFLIX SEARCH Shift + Red / Netflix /	↔	SHIFT + RETURN BACK Shift + Back / Return
SOURCE	RDS AV INPUT AV / Input / RDS	TV GUIDE	-/-- GUIDE EPG Guide / EPG / -/--
PRESETS	LIST SMART Smart / List	[≡]	GOTO TEXT Text / Goto
┼┼┼	OPT-TOOLS SETUP Setup / OPT /	MENU	HOME MENU Menu / Home
♫/ ☺ ◘	MEDIA DISPLAY Display / Media	Q. MENU	TOP MENU D.MENU D. Menu / Top
SLEEP	TIMER SLEEP Sleep / Timer	UP	Up
1 . /@	TV 1 1	LEFT	Left
2 abc	DVD 2 2	OK	OK
3 def	CD - STB 3 3	RIGHT	Right
4 ghi	VIDEO 4 4	DOWN	Down
5 jkl	TAPE 5 5	BACK	RETURN BACK Back / Return
6 mno	TUNER 6 6	⊸⊷	FORMAT PICTURE Picture / Format
7 pqrs	AUX - HDD 7 7	EXIT	CLEAR EXIT CANCEL Exit / Cancel / Clear
8 tuv	USB 8 8	☼FAV	PC FAV MARKER Fav / Marker / PC

Original	Replacement	Original	Replacement
VOL+	Vol +	BLUE	Blue / Prime Video / Random
MUTE	Mute / Dimmer		
P+	CH+ / Page+		
VOL-	Vol -		
INFO	Info / Angle		
P-	CH- / Page-		
REC	Rec / Rec Mode		
PLAY	Play / Slow		
PAUSE	Pause / Step / Freeze		
STOP	Stop / Hold		
LANG.	Audio / Lang I/II		
<<	<< / Tune-		
>>	>> / Tune+		
[≡]...	Sound / Title		
RED	Red / Netflix / Search		
GREEN	Green / APP / Repeat		
YELLOW	Yellow / YouTube / Repeat		