Mandis shop

Medion

Original		Replacement	
	Power		Power
OPTICAL	Optical	USB 8	8
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
AUX	AUX	AUX - HDD 7	7
BT	BT	BLUETOOTH 9	9
HDMI ARC	HDMI ARC	HDMI - SAT 0	0
BASS +	Bass+	+ CH PAGE	CH+ / Page+
VOL+	Up / Vol+		Up
VOL+	Up / Vol+	+ VOL	Vol+
TREB+	Treb+	TUNE+ ▶▶	>> / Tune+
⏮	Left / I<<	PRESET- ⏮	I<< / Preset-
⏮	Left / I<<		Left
▶II/PAIR	Play/Pause / Pair	LIST SMART	Smart / List
▶II/PAIR	Play/Pause / Pair	STEP - FREEZE II	Pause / Step / Freeze
▶II/PAIR	Play/Pause / Pair	SLOW ▶	Play / Slow
⏭	Right / >>I	PRESET+ ⏭	>>I / Preset+
⏭	Right / >>I		Right

Original		Replacement	
BASS –	Bass-	CH PAGE –	CH- / Page-
VOL–	Down / Vol-	VOL –	Vol-
VOL–	Down / Vol-		Down
TREB–	Treb-	TUNE- ◀◀	<< / Tune-
FLAT	Flat	NETFLIX SEARCH	Red / Netflix / Search
MOVIE	Movie	APP REPEAT	Green / APP / Repeat
MUSIC	Music	YouTube REPEAT A-B	Yellow / YouTube / Repeat

https://all-remote-controls.co.uk/en/Medion/1065995-92624-replacement-remote-control-for-Medion-50061233.html