Mandis shop

Nakamichi AMPLIFIER1

Original		Replacement		Original	Replacement
Power	Power		Power		
Phono	Phono	1	1		
CD	CD	2	2		
Tuner	Tuner	3	3		
Aux	Aux	4	4		
Tape1	Tape1	5	5		
Tape2	Tape2	6	6		
Vol+	Vol+	VOL +	Vol +		
Vol-	Vol-	VOL −	Vol -		
Mute	Mute	MUTE	Mute		

https://all-remote-controls.co.uk/en/Nakamichi/1063872-94237-replacement-remote-control-for-Nakamichi-Amplifier1.html