Original		Replacement	
	Power		Power
PICTURE	Picture	PICTURE FORMAT	Format
SOUND	♪/Sound	SOUND DUAL	Dual
SET UP	Set Up	TOP MENU MENU	Menu
	CH+	+ CH	Ch +
	CH-	CH −	Ch -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -
	Mute	MUTE	Mute
	[+]	DISPLAY INFO	Info
TV/AV	Tv/AV	TIMER AV	AV
	Red	A	Red
	Green	B	Green

Original		Replacement	
	Yellow	C	Yellow
	Blue	D	Blue
F.P.	[≡♦]/FP	SEARCH TV/R	TV/R
INDEX	[≡i]/Index	HOME SMART	Smart
HOLD STILL	[≡+]/Hold/Still	SETTINGS OPT	Options
TV/TEXT	Tv/Text	REPEAT TEXT	Text
DIRECT TV REC	Direct Tv Rec	REC MODE	Rec
	OIO	DISC NAV LIST	List
ASPECT	Aspect	ECO 3D	3D
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8

Original		Replacement	
9	9	9	9
VCR 0	0/VCR	0	0
C	C	FAV PRE-CH	Pre Ch
-/--	-/--	-/-- GUIDE	Guide
▶	Play	PLAY MODE ▶	Play
■	Stop	■	Stop
▶▶	>>	»	>>
◀◀	<<	«	<<

Original	Replacement

Original		Replacement	
DVD VCR	Power		Power
N	N	SETTINGS OPT	Options
PROGRAMME	Programme+	CH +	Ch +
PROGR	Programme-	CH −	Ch -
STR	STR	HOME SMART	Smart
HELP ?	?/Help	APP MEDIA	Media

Original	Replacement

Original		Replacement	
DVD VCR	Power		Power
REC	Rec	REC MODE	Rec
II/I>		II	Pause
PROGR	Programme-	CH –	Ch -
RAMME	Programme+	+ CH	Ch +
HELP ?	?/Help	APP MEDIA	Media
STR	STR	HOME SMART	Smart
N	N	SETTINGS OPT	Options

Original	Replacement