Original		Replacement	
	Power		Power
	Power TV	SHIFT +	Shift + Power
AV	AV TV	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
VOL +	Vol + TV	SHIFT +	Shift + Right
BD/SD	BD/SD	SHIFT + MEDIA DISPLAY	Shift + Display / Media
FM	FM	PROGRAM TV/RADIO	TV/Radio /
iPod	iPod	LIST SMART	Smart / List
VOL −	Vol - TV	SHIFT +	Shift + Left
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
SELECT >	Select >	CH PAGE +	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
SELECT <	< Select	CH PAGE −	CH- / Page-
7	7	AUX-HDD 7	7

Original		Replacement	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VOL +	Vol +	VOL +	Vol +
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
0	0	HDMI-SAT 0	0
AUDIO	Audio/FM Mode	LANG I/II AUDIO	Audio / Lang I/II
VOL −	Vol -	VOL −	Vol -
SKIP	I<< Skip	PRESET-	I<< / Preset-
SKIP	Skip >>I	PRESET+	>>I / Preset+
SLOW/SEARCH	<< Slow/Search	TUNE-	<< / Tune-
SLOW/SEARCH	Slow/Search >>	TUNE+	>> / Tune+
STOP	Stop	HOLD	Stop / Hold
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
PLAY	Play	SLOW	Play / Slow
DISPLAY	Display	MEDIA DISPLAY	Display / Media
POP-UP MENU	Pop-Up Menu	TOP MENU D.MENU	D.Menu / Top
ONE TOUCH PLAY	One Touch Play	PC FAV MARKER	Fav / Marker / PC

Original	Replacement	Original	Replacement
Top Menu/Direct Navigator	Menu / Home	Dolby VS	AV / Input / RDS
Up	Up	Dolby PLIIx	Picture / Format
OK	OK	NEO:6	Subtitle / EQ
Functions	Guide / EPG / -/--	7.1CH VS	Info / Angle
Left	Left	Sound	Sound / Title
Right	Right	Sleep	Sleep / Timer
Option	Shift + Setup / OPT / Tools	CH Select	Eject / Surround
Down	Down	Muting	Mute / Dimmer
Return	Back / Return		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
Setup	Setup / OPT /		
PIP	Zoom / Size		
Audio	Shift + Audio / Lang I/II		
Status	Text / Goto		