Original		Replacement	
	Power		Power
OK	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	>>		>>
	Left		Left
	<<		<<
BACK	Back	RETURN BACK	Back
OPTIONS	Options	SETTINGS OPT	Options
DISC	Disc	TOP MENU MENU	Menu
OPEN/CLOSE	Open/Close	ZOOM	Eject
	Mute	MUTE	Mute
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
	Stop		Stop
	>I		>>I

Original		Replacement	
	Play/Pause	PLAY MODE	Play
	I<		I<<
	Home	HOME SMART	Smart
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
SOUND	Sound	SOUND DUAL	Dual
SURR	Surr	AD SUBT	Subt
AUDIO SOURCE	Source/Audio	TIMER AV	AV
RADIO	Radio	SEARCH TV/R	TV/R

Original		Replacement		Original	Replacement
USB	USB	PICTURE FORMAT	Format		
AUDIO SYNC	Sync/ Audio	ECO 3D	3D		