Original		Replacement	
	Power		Power
	[i+]/Info	DISPLAY INFO	Info
	[+]/Search	SEARCH TV/R	TV/R
	[..≡]/Title	SETTINGS OPT	Options
	DVD Menu	E-MANUAL D.MENU	D. Menu
	[*]/Mark	APP MEDIA	Media
	[--]/A-B	SOUND DUAL	Dual
	[+]/Zoom	ZOOM	Eject
	[?]/Clear	CLEAR EXIT	Exit
	<<Fast		<<
	>>Fast		>>
	<<Skip		I<<
	>>Skip		>>I
	Stop/Eject		Stop
	Pause/Play	PLAY MODE	Play
	Menu	TOP MENU MENU	Menu
	Enter	OK	Ok

Original		Replacement	
	Vol+	+ VOL	Vol +
	Vol-	VOL –	Vol -
	Mute	MUTE	Mute
	PR+	+ CH	Ch +
	PR-	CH –	Ch -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Red/Audio I-II	A	Red
	Green/Repeat	B	Green
	Yellow/Angle	C	Yellow
	Blue/Sub	D	Blue
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4

Original		Replacement		Original	Replacement
5	5	5	5		
6	6	6	6		
7	7	7	7		
8	8	8	8		
9	9	9	9		
0	0	0	0		
AV	AV	TIMER AV	AV		
16:9	16:9	PICTURE FORMAT	Format		