Original	Replacement
Standby / On	Power
VCR Eject	SHIFT + SURROUND (Shift + Eject / Surround)
DVD Open / Close	SURROUND (Eject / Surround)
DVD / VCR	SMART (Smart / List)
1	1
2	2
3	3
Timer Rec	SLEEP (Sleep / Timer)
4	4
5	5
6	6
Input Select	AV INPUT (AV / Input / RDS)
7	7
8	8
9	9
ShowView	Prime Video / RANDOM (Blue / Prime Video / Random)
0	0

Original	Replacement
Return	BACK (Back / Return)
Cancel	EXIT (Exit / Cancel / Clear)
Up / CH +	Up
Up / CH +	CH+ / Page+
Title Menu / Top Menu	MENU (Menu / Home)
Left / TRK -	Left
Enter	OK
Right / TRK +	Right
DVD Menu	D.MENU (D. Menu / Top)
Down / CH -	Down
Down / CH -	CH- / Page-
Setup	SETUP (Setup / OPT /
Stop	HOLD (Stop / Hold)
Play	SLOW (Play / Slow)
Pause / Still	STEP-FREEZE (Pause / Step / Freeze)
<< Skip / Index	PRESET- (<< / Preset-)
<< Rew / Search	TUNE- (<< / Tune-)

Original	Replacement	Original	Replacement
>> F. Fwd /	TUNE+ >> / Tune+	TV / VCR	PROGRAM TV/RADIO TV/ Radio /
>>I Skip / Index	PRESET+ >>I / Preset+		
One Touch	NETFLIX SEARCH Red / Netflix / Search		
CM Skip	FORMAT PICTURE Picture / Format		
Slow I>	SHIFT + SLOW Shift + Play /		
Rec	REC MODE Rec / Rec Mode		
Rec Mode / Speed	SHIFT + REC MODE Shift + Rec / Rec Mode		
Dubbing	PC FAV MARKER Fav / Marker / PC		
Audio / Audio select	LANG I/II AUDIO Audio / Lang I/II		
Display	MEDIA DISPLAY Display / Media		
Zoom	SIZE ZOOM Zoom / Size		
Repeat A-B	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Zero Return	SHIFT + RETURN BACK Shift + Back / Return		
Counter Reset / Angle	ANGLE INFO Info / Angle		
Subtitle / ATR	EQ SUBTITLE Subtitle / EQ		
Play Mode /	APP REPEAT Green / APP / Repeat		
Clock Counter	GOTO TEXT Text / Goto		