Mandis shop

QUESTAR DV900

Original	Replacement
Power	Power
Open/Close	Eject / Surround
Mute	Mute / Dimmer
1	1
2	2
3	3
Info	Info / Angle
4	4
5	5
6	6
Clear	Shift + Exit / Cancel / Clear
7	7
8	8
9	9
Video	Shift + 4
0	0
Menu	Menu / Home

Original	Replacement
Title	Sound / Title
Exit	Exit / Cancel / Clear
<<	<< / Tune-
>>	>> / Tune+
Zoom	Zoom / Size
Left	Left
Up	Up
Right	Right
>>I	>>I / Preset+
OK	OK
Down	Down
I<<	I<< / Preset-
Stop	Stop / Hold
Play	Play / Slow
Pause	Pause / Step / Freeze
≡	D.Menu / Top

https://all-remote-controls.co.uk/en/1060791-82313-replacement-remote-control-for-QUESTAR-DV900.html