Original		Replacement	
POWER	Power		Power
SOURCE	Source	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TTX/MIX	TTX/MIX	REPEAT TEXT	Text
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
MUTE	Mute	MUTE	Mute
CH LIST	CH List	DISC NAV LIST	List
MENU	Menu	TOP MENU MENU	Menu

Original		Replacement	
GUIDE	Guide	GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
SMART HUB	Smart Hub	HOME SMART	Smart
INFO	Info	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
	Enter	OK	Ok
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
A	Red	A	Red
B	Green	B	Green
C	Yellow	C	Yellow
D	Blue	D	Blue
SOCIAL TV	Social Tv	APP MEDIA	Media
	3D	ECO 3D	3D

Original		Replacement	
P.SIZE	P.Size	PICTURE FORMAT	Format
AD/SUBT.	AD/Subt.	AD SUBT	Subt
SEARCH	Search	SEARCH TV/R	TV/R
E-MANUAL	E-Manual	E-MANUAL D.MENU	D. Menu
▶	Play	PLAY MODE ▶	Play
●	Rec	REC MODE ●	Rec
■	Stop	■	Stop
II	Pause	II	Pause
<<|<<	<<|<<	<<	<<
>>|>>|	>>|>>|	>>	>>
+	Vol+	+ VOL	Vol +
–	Vol-	VOL –	Vol -
P	P+	+ CH	Ch +
P	P-	CH –	Ch -

Original	Replacement