Original		Replacement	
POWER	Power		Power
	Open/Close	SURROUND	Eject / Surround
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
TIMER ON/OFF	On/Off Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
DVD	DVD	SHIFT + DVD 2	Shift + 2
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
TIMER/CLOCK	Timer/Clock	FORMAT PICTURE	Picture / Format
PORT	Port	SHIFT + CD-STB 3	Shift + 3
AUX	AUX	SHIFT + AUX-HDD 7	Shift + 7
1	1/RDS Display	TV 1	1
2	2	DVD 2	2
3	3/TA	CD-STB 3	3
4	4/PTY-	VIDEO 4	4
5	5/PTY Search	TAPE 5	5
6	6/PTY+	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8

Original		Replacement	
9	9	BLUETOOTH 9	9
CD RIPPING	CD Ripping	GOTO TEXT	Text / Goto
0	0	HDMI-SAT 0	0
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random
	I<<	PRESET-	I<< / Preset-
STEP	Step	SHIFT + STEP-FREEZE	Shift + Pause / Step /
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
STOP	Stop	HOLD	Stop / Hold
PLAY	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
VOL +	Vol +	VOL	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
TUNING	Tuning Up	CH PAGE	CH+ / Page+
VOL -	Vol -	VOL	Vol -
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II

Original		Replacement	
TUNING	Tuning Down	CH PAGE	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
RETURN	Return	RETURN BACK	Back / Return
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
INFO	Info	ANGLE INFO	Info / Angle
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
REPEAT A-B	A-B Repeat	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TUNER MEMORY	Tuner Memory	REC MODE	Rec / Rec Mode
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
DSP/EQ	DSP/EQ	MEDIA DISPLAY	Display / Media
P.SOUND	P.Sound	TITLE SOUND	Sound / Title
TREB/BASS	Treb/Bass	PROGRAM TV/ RADIO	TV/Radio / Program

Original		Replacement	
P.BASS	P.Bass	PC FAV MARKER	Fav / Marker / PC
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
SLOW	Slow	SHIFT + SLOW	Shift + Play /
ANGLE	Angle	SHIFT + ANGLE INFO	Shift + Info / Angle
REMAIN	Remain	LIST SMART	Smart / List
MO/ST	Mo/St	OPT-TOOLS SETUP	Setup / OPT /
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
CANCEL	Cancel	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
DEMO	Demo	TOP MENU D.MENU	D.Menu / Top