Original		Replacement	
POWER	Power		Power
TV/DTV	TV / DTV	SEARCH TV/R	TV/R
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	SHIFT + -/-- GUIDE	Shift + Guide
PRE-CH	Pre-CH	FAV PRE-CH	Pre Ch
+	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute

Original		Replacement	
SOURCE	Source	TIMER AV	AV
P	P +	+ CH	Ch +
P	P -	CH −	Ch -
GUIDE	Guide	-/-- GUIDE	Guide
MENU	Menu	TOP MENU MENU	Menu
W.LINK	W Link	HOME SMART	Smart
TOOLS	Tools	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK	OK	Ok
INFO	Info	DISPLAY INFO	Info
EXIT	Exit	CLEAR EXIT	Exit
	Red	A	Red
	Green	B	Green

Original		Replacement	
	Yellow	C	Yellow
	Blue	D	Blue
TTX/MIX	TTX / Mix	REPEAT TEXT	Text
P.SIZE	P. Size	PICTURE FORMAT	Format
DMA	DMA	ECO 3D	3D
E.MODE	E. Mode	SOUND DUAL	Dual
CH LIST	CH. List	DISC NAV LIST	List
SUBT.	Subt.	AD SUBT	Subt
<<	<<	<<	<<
I <<	I <<	I <<	I <<
Pause	Pause	Pause	Pause
>>	>>	>>	>>
>>I	>>I	>>I	>>I
Rec	Rec	REC MODE	Rec
Play	Play	PLAY MODE	Play
Stop	Stop	Stop	Stop

Original	Replacement