Mandis shop

Samsung AH59-01159J

Original		Replacement	
MUTE	Mute	MUTE	Mute
⏻/I	Power	⏻	Power
TUNER BAND	Tuner/Band	B	Green
AUX	AUX	A	Red
TIMER/CLOCK	Timer/Clock	FAV PRE-CH	Pre Ch
TIMER ON/OFF	Timer On/Off	CLEAR EXIT	Exit
PROGRAM/SET	Program/Set	TOP MENU MENU	Menu
REP. A↔B MO/ST	Mo/ST/Rep A-B	SOUND DUAL	Dual
SLEEP	Sleep	PROG SLEEP	Sleep
EQ/S.BASS	EQ/S.Bass	SETTINGS OPT	Options
TAPE SPEED	Tape Speed	PICTURE FORMAT	Format
POWER SOUND	Power Sound	APP MEDIA	Media
DISPLAY-RD	Display	DISPLAY INFO	Info
RDS-PTY	RDS-PTY	SEARCH TV/R	TV/R
►/II	Play CD/MP3-CD	PLAY MODE ►	Play
►/II	Pause	II	Pause
■	Stop	■	Stop

Original		Replacement	
⏮	I<< CD/MP3-CD	⏮	I<<
⏭	>>I CD/MP3-CD	⏭	>>I
REPEAT	Repeat	REPEAT TEXT	Text
VOLUME +	Volume+	+ VOL	Vol +
−	Volume-	VOL −	Vol -
TUNING/ ALBUM ^	Tuning/Album	+ CH	Ch +
v	Tuning/Album	CH −	Ch -
TUNING MODE +10	+10TUning	-/-- GUIDE	Guide
◄◄	<< Tape	◄◄	<<
►►	>> Tape	►►	>>
PE ►	Play Tape	SHIFT + PLAY MODE ►	Shift + Play
TA ■	Stop Tape	SHIFT + ■	Shift + Stop

CD/MP3-CD

https://all-remote-controls.co.uk/en/Samsung/1059680-3580-replacement-remote-control-for-Samsung-AH59-01159J.html