Mandis shop

# Samsung BP5900139A

| Original | | Replacement | |
|---|---|---|---|
| ON | On | | Power |
| AUTO | Auto | 2 | 2 |
| OFF | Off | SHIFT + | Shift + Power |
| MENU | Menu | MENU | Menu / Home |
| RETURN | Return | BACK | Back / Return |
| | Up | | Up |
| | Left | | Left |
| | Enter | OK | OK |
| | Right | | Right |
| | Down | | Down |
| V.KEY-STONE | V.Keystone+ | CH PAGE | CH+ / Page+ |
| BLANK | Blank | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| INFO | Info | ANGLE INFO | Info / Angle |
| V.KEY-STONE | V.Keystone- | CH PAGE | CH- / Page- |
| STILL | Still | STEP-FREEZE | Pause / Step / Freeze |
| VIDEO | Video | 4 | 4 |
| COMP | Comp | 1 | 1 |

| Original | | Replacement | |
|---|---|---|---|
| HDMI | HDMI | 0 | 0 |
| S-VIDEO | S-Video | 5 | 5 |
| PC | PC | FAV MARKER | Fav / Marker / PC |
| INSTALL | Install | D.MENU | D.Menu / Top |
| P.SIZE | P.Size | ZOOM | Zoom / Size |
| P.MODE | P.Mode | PICTURE | Picture / Format |

https://all-remote-controls.co.uk/en/Samsung/1066751-3426-replacement-remote-control-for-Samsung-TM91-BP59-00139A.html