Mandis shop

SEAGATE001

Original		Replacement	
	Power		Power
	Home	HOME SMART	Smart
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
	Back	RETURN BACK	Back
Menu	Menu	TOP MENU MENU	Menu
	i	DISPLAY INFO	Info
	<<		<<
	>>		>>
	Play / Pause	PLAY MODE	Play
	Play / Pause		Pause
	I<<		I<<
	>>I		>>I
	Stop		Stop

Original		Replacement	
Volume	Volume+	VOL +	Vol +
Volume	Volume-	VOL −	Vol -
Mute	Mute	MUTE	Mute
Zoom	Zoom+	CH +	Ch +
Zoom	Zoom-	CH −	Ch -

https://all-remote-controls.co.uk/en/Seagate/1061777-24562-replacement-remote-control-for-Seagate-GOFLEX-CINEMA.html