Original		Replacement	
OPERATE	Operate		Power
OPEN/CLOSE	Open/Close	ZOOM	Eject
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	GUIDE	Guide
TV/DVD	Tv/DVD	SEARCH TV/R	TV/R
CH	CH+	+ CH	Ch +
	CH-	CH −	Ch -
DIRECT	Direct	SETTINGS OPT	Options

Original		Replacement	
ERASE C	C/Erase	ECO 3D	3D
SHOWVIEW	ShowView	PICTURE FORMAT	Format
HDD	HDD	HOME SMART	Smart
DVD	DVD	APP MEDIA	Media
INPUT	Input	TIMER AV	AV
START MENU	Start Menu	TOP MENU MENU	Menu
ORIGINAL/ PLAY LIST DVD MENU	DVD Menu/Original	SHIFT + TOP MENU MENU	Shift + Menu
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
REC LIST DVD TITLE	DVD Title/Rec List	E-MANUAL D.MENU	D. Menu
SET/ ENTER	SET/Enter	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
DUBBING	Dubbing	DISC NAV LIST	List
P IN P	P IN P	REPEAT TEXT	Text

Original	Replacement
Timer On/Off	SHIFT + TIMER AV (Shift + AV)
Timeshift	SHIFT + -/-- GUIDE (Shift + Guide)
Blue/A-B	D (Blue)
Red/B	A (Red)
Green/C	B (Green)
Yellow/D	C (Yellow)
Play	PLAY MODE ▶ (Play)
<<\/REV	<<
>>\/FWD	>>
Stop/Live	■ (Stop)
Still/Pause	II (Pause)
I>/Slow	PROG SLEEP (Sleep)
Rec	REC MODE ● (Rec)
Stop Rec	SHIFT + ■ (Shift + Stop)
Pause Rec	SHIFT + II (Shift + Pause)
>>I/F.ADV Skip	>>I
I<<\/<I F.ADV	I<<

Original	Replacement
Replay	SHIFT + PLAY MODE ▶ (Shift + Play)
Skip Search	SHIFT + SEARCH TV/R (Shift + TV/R)
Zoom/Rec Mode	SHIFT + REC MODE ● (Shift + Rec)
Function	SHIFT + E-MANUAL D.MENU (Shift + D. Menu)
Audio	SOUND DUAL (Dual)
Angle	SHIFT + A (Shift + Red)
Subtitle	AD SUBT (Subt)
Direct Rec Tv	SHIFT + REPEAT TEXT (Shift + Text)
Tamper Proof/On Screen	SHIFT + PICTURE FORMAT (Shift + Format)
RGB Off/Chapter Mark	SHIFT + FAV PRE-CH (Shift + Pre Ch)
Operate Tv	SHIFT + ⏻ (Shift + Power)
Back	DISPLAY INFO (Info)
Vol+ Tv Control	+ VOL (Vol +)
Vol- Tv Control	VOL – (Vol -)
CH+ Tv Control	SHIFT + + CH (Shift + Ch +)
CH- Tv Control	SHIFT + CH – (Shift + Ch -)
Input Tv Control	FAV PRE-CH (Pre Ch)