Original		Replacement	
ON/ STAND-BY	On / Standby		Power
OPEN / CLOSE	Open / Close	SURROUND	Eject / Surround
TUNER(BAND)	Tuner (Band)	SHIFT + TUNER 6	Shift + 6
ASPM	ASPM	OPT-TOOLS SETUP	Setup / OPT /
RDS PTY	RDS - PTY	TOP MENU D.MENU	D. Menu / Top
DISPLAY	Display	MEDIA DISPLAY	Display / Media
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
X-BASS	X-Bass	LANG I/II AUDIO	Audio / Lang I/II
BASS / TREBLE	Bass / Treble	TITLE SOUND	Sound / Title
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
MEMORY	Memory	SHIFT + LIST SMART	Shift + Smart / List
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Original		Replacement	
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
CLOCK / TIMER	Clock / Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
0	0	HDMI - SAT 0	0
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
PLAY MODE	Play Mode	SLOW ▶	Play / Slow
FOLDER	Folder	GOTO TEXT	Text / Goto
DISPLAY (TV OUT)	(Tv Out) / Displ iPod / iPhone	PROGRAM TV/ RADIO	TV/ Radio /
MENU	Menu iPod /	HOME MENU	Menu / Home
▶/II	Play/Pause iPod iPhone	STEP - FREEZE II	Pause / Step / Freeze
DISPLAY	Display CD / USB	SHIFT + MEDIA DISPLAY	Shift + Display / Media
■	Stop CD / USB	HOLD ■	Stop / Hold
▶/II	Play/Pause CD /	SHIFT + SLOW ▶	Shift + Play /
TUNING	I<< / <<	PRESET- ⏮	I<< / Preset-
PRESET	Preset Up	▲	Up

Original	Replacement
>>I / >>	>>I / Preset +
Vol -	Vol -
Enter	OK
Vol +	Vol +
Equalizer Mode	Shift + Audio / Lang I/II
Preset Down	Down
Demo / Dimmer	Shift + Mute / Dimmer
iPod / iPhone	Smart / List
CD	Shift + 3
USB	Shift + 8
Input / Audio / Line	AV / Input / RDS

Original	Replacement