Original		Replacement	
	Power		Power
	Open/Close	ZOOM	Eject
POP-UP MENU	Pop-Up Menu	TOP MENU MENU	Menu
HOME	Home	HOME SMART	Smart
TITLE LIST TOP MENU	Top Menu/Title	APP MEDIA	Media
DISPLAY	Display	DISPLAY INFO	Info
FUNCTION	Function	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
A	Red	A	Red
ENTER	Enter	OK	Ok
B	Green	B	Green
C	Yellow	C	Yellow

Original		Replacement	
D	Blue	D	Blue
AUDIO	Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
ANGLE	Angle	-/-- GUIDE	Guide
PinP	PinP	PICTURE FORMAT	Format
REPEAT	Repeat	REPEAT TEXT	Text
OFF	Off	E-MANUAL D.MENU	D. Menu
PAGE	Page Up	+ CH	Ch +
	Page Down	CH −	Ch -
LIGHT	Light	DISC NAV LIST	List
RESET	Reset	FAV PRE-CH	Pre Ch
	Key	PROG SLEEP	Sleep
	Play	PLAY MODE	Play
REV	<<		<<
3D	3D	ECO 3D	3D
FWD	>>		>>
SKIP	I <<		I <<

Original		Replacement	
	Pause		Pause
SKIP	>>I		>>I
REPLAY	Replay	SHIFT + PLAY MODE	Shift + Play
	Stop		Stop
SKIP SEARCH	Skip Search	SEARCH TV/R	TV/R
	Power Tv	SHIFT +	Shift + Power
INPUT	Input Tv	SHIFT + TIMER AV	Shift + AV
CH	CH+ Tv	SHIFT + + CH	Shift + Ch +
	CH- Tv	SHIFT + CH −	Shift + Ch -
VOL	Vol + Tv	+ VOL	Vol +
	Vol - Tv	VOL −	Vol -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6

Original		Replacement	
8	8	8	8
7	7	7	7
0	0	0	0
9	9	9	9
ENTER	Enter	SHIFT + OK	Shift + Ok
CLEAR	Clear	SHIFT + CLEAR EXIT	Shift + Exit