Mandis shop

SH470

Original	Replacement	Original	Replacement
Power	Power		
Line	Guide / EPG / -/--		
BT	9		
+	Up		
-	Down		
I<<	I<< / Preset-		
I<<	Shift + I<< / Preset-		
>>I	Shift + >>I / Preset+		
Play	Shift + Play /		
>>I	>>I / Preset+		
Play/Pause	Play / Slow		
Pause	Pause / Step / Freeze		
EQ	Subtitle / EQ		
OPT/ARC	Setup / OPT /		
Mute	Mute / Dimmer		

https://all-remote-controls.co.uk/en/Sharp/1065259-92989-replacement-remote-control-for-Sharp-SH470.html