Original		Replacement	
	Power		Power
	Source		AV / Input / RDS
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Mute		Mute / Dimmer
	Guide		Guide / EPG / -/--
	Menu		Menu / Home
	Smart Colors		Smart / List
	Info		Info / Angle

Original		Replacement	
	Up		Up
	Down		Down
	Left		Left
	Right		Right
	OK		OK
	Back		Back / Return
	Home		Shift + Menu /
	Exit		Exit / Cancel / Clear
	Vol +		Vol +
	Vol -		Vol -
	CH+		CH+ / Page+
	CH-		CH- / Page-
	Netflix		Shift + Red / Netflix /
	prime video		Shift + Blue / Prime
	YouTube		Shift + Yellow / YouTube /
	FPlay		Shift + Green / APP /
	Audio		Audio / Lang I/II

Original		Replacement		Original	Replacement
SUB	Sub	EQ SUBTITLE	Subtitle / EQ		
TEXT	Text	GOTO TEXT	Text / Goto		
TV	TV	PROGRAM TV/RADIO	TV/Radio /		
▶II	Play	SLOW ▶	Play / Slow		
▶II	Pause	STEP-FREEZE II	Pause / Step / Freeze		
◀◀	<<	TUNE- ◀◀	<< / Tune-		
▶▶	>>	TUNE+ ▶▶	>> / Tune+		
■	Stop	HOLD ■	Stop / Hold		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		