Mandis shop

Sharp HTSB140

Original		Replacement		Original	Replacement
	Power		Power		
OPTICAL	Optical	SLOW	Play / Slow		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
AUX	AUX	STEP-FREEZE	Pause / Step / Freeze		
BT	BT	HOLD	Stop / Hold		
HDMI ARC	HDMI ARC	REC MODE	Rec / Rec Mode		
VOL+	Vol+	VOL +	Vol+		
I<	I<		Left		
⏯/PAIR	Play/Pause/Pair	OK	OK		
>I	>I		Right		
VOL–	Vol-	VOL –	Vol-		
NEWS	News	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
MOVIE	Movie		Down		
MUSIC	Music	RETURN BACK	Back / Return		

https://all-remote-controls.co.uk/en/Sharp/1067466-95598-replacement-remote-control-for-Sharp-HTSB140-105001157.html