Mandis shop

Sony RM-SR110

Original		Replacement	
	Power		Power
	Play Function		Yellow
	Play Tape B		Green
	Play Tuner / Band		TV/R
	Play Tape A		Red
	Flash		Info
	Loop		Back
	File Select		Media
	Mode Select		Smart
	Vol +		Vol +
	Vol -		Vol -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	>>		>>

Original		Replacement	
	<<		<<
	>>I / +		>>I
	I<< / -		I<<
	Stop		Stop
	Pause		Pause
	Play CD		Play
	Disc Skip		Exit
	Sleep		Sleep

https://all-remote-controls.co.uk/en/Sony/1057363-91101-replacement-remote-control-for-Sony-RMSR110-141886211.html