Mandis shop

Sony RMSR5

Original		Replacement	
DISC SKIP	Disc Skip	Prime Video / RANDOM	Blue / Prime Video / Random
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
I/⏻	Power	⏻	Power
CD	CD Play	SLOW ▶	Play / Slow
⏸	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
TUNER/BAND	Tuner/Band	YouTube / REPEAT A-B	Yellow / YouTube / Repeat
⏮	I<<	PRESET- ⏮	I<< / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
DECK A	Deck A Play	NETFLIX / SEARCH	Red / Netflix / Search
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
DECK B	Deck B Play	APP / REPEAT	Green / APP / Repeat
CHECK	Check	MEDIA DISPLAY	Display / Media
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MD	MD Play	SHIFT + SLOW ▶	Shift + Play /
⏸	Pause MD	SHIFT + STEP-FREEZE ⏸	Shift + Pause / Step / Freeze

Original		Replacement	
■	Stop MD	SHIFT + HOLD ■	Shift + Stop /
LOOP	Loop	LIST SMART	Smart / List
FLASH	Flash	ANGLE INFO	Info / Angle
FUNCTION	Function	HOME MENU	Menu / Home
FILE SELECT	Up	▲	Up
VOL	Vol +	+ VOL	Vol+
I/⏻	On /Off	OK	OK
	Down	▼	Down
	Vol -	VOL −	Vol-

https://all-remote-controls.co.uk/en/Sony/1058651-23109-replacement-remote-control-for-Sony-RM-SR5-147557211.html