Mandis shop

RM-ST1

| Original | | Replacement | |
|---|---|---|---|
| TIMER SELECT | Timer Select | SHIFT + TIMER SLEEP | Shift + Sleep / Timer |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| SYSTEM POWER | System Power | | Power |
| TIMER SET | Timer Set | SHIFT + OPT-TOOLS SETUP | Shift + Setup / OPT / Tools |
| – TIMI | Timer- | CH PAGE – | CH- / Page- |
| MER + | Timer+ | + CH PAGE | CH+ / Page+ |
| | Play CD/Tuner | SLOW ▶ | Play / Slow |
| | Pause CD/Tuner | STEP - FREEZE ❚❚ | Pause / Step / Freeze |
| | Stop CD/Tuner | SHIFT + HOLD ■ | Shift + Stop / |
| BAND | Band CD/Tuner | CD - STB 3 | 3 |
| – TUN | I<<Tuning- CD/Tuner | PRESET- ⏮ | I<< / Preset- |
| NING + | >>I/Tuning+ CD/Tuner | PRESET+ ⏭ | >>I / Preset+ |
| STEREO/ MONO | Stereo/Mono CD/Tuner | TITLE SOUND | Sound / Title |
| TUNING/ PLAY MODE | Tuning/Play Mode CD/Tuner | TAPE 5 | 5 |
| REPEAT | Repeat | RETURN BACK | Back / Return |
| DISPLAY | Display CD/Tuner | MEDIA DISPLAY | Display / Media |
| MEMORY | Memory | TUNER 6 | 6 |

| Original | | Replacement | |
|---|---|---|---|
| ENTER | Enter | OK | OK |
| | < Tape | SHIFT + TUNE- ◀◀ | Shift + << / |
| | > Tape | SHIFT + TUNE+ ▶▶ | Shift + >> / |
| | Stop Tape | HOLD ■ | Stop / Hold |
| FUNCTION | Function | OPT-TOOLS SETUP | Setup / OPT / |
| | << Tape | TUNE- ◀◀ | << / Tune- |
| | >> Tape | TUNE+ ▶▶ | >> / Tune+ |
| DBFB | DBFB | DVD 2 | 2 |
| SURROUND | Surround | SURROUND ⏏ | Eject / Surround |
| + VOL | Vol+ | + VOL | Vol+ |
| BALAN L | Balance L | ◀ | Left |
| ANCE R | Balance R | ▶ | Right |
| VOL – | Vol- | VOL – | Vol- |

CD/Tuner

https://all-remote-controls.co.uk/en/Sony/1059504-85143-replacement-remote-control-for-Sony-RM-ST1.html