Mandis shop

RM-SD50

Original	Replacement
Power	Power
Sleep	Sleep
Loop	Smart
Play CD	Play
Pause CD	Pause
Stop CD	Stop
Play	Yellow
I<< Tuner/Band	I<<
>>I Tuner/Band	>>I
Play Deck A	Red
<< Deck A	<<
>> Deck A	>>
Play Deck B	Green
Check	Pre Ch
Edit	Blue
Function	Menu
Clear	Exit

Original	Replacement
Disc Skip	Media
Vol+	Vol +
Vol-	Vol -
Up	Up
Down	Down
Right	Right
Left	Left
On/Off	Ok

https://all-remote-controls.co.uk/en/Sony/1063680-90875-replacement-remote-control-for-Sony-RM-SD50.html