Mandis shop

RMT-812

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Photo | Smart / List | <\|<II | Left |
| Zero Set | Setup / OPT / | Stop | Stop / Hold |
| Start/Stop | Power | >/II> | Right |
| Display | Display / Media | Pause | Pause / Step / Freeze |
| Data Code | Menu / Home | Slow I> | Sleep / Timer |
| T | Up | X2 | Zoom / Size |
| Play Memory | Exit / Cancel / Clear | Mark | Fav / Marker / PC |
| Index Memory | Info / Angle | Audio Dub | Audio / Lang I/II |
| Memory- | Vol- | | |
| Memory+ | Vol+ | | |
| W | Down | | |
| Search Mode | Red / Netflix / Search | | |
| I<< | I<< / Preset- | | |
| >>I | >>I / Preset+ | | |
| << | << / Tune- | | |
| Play | Play / Slow | | |
| >> | >> / Tune+ | | |

https://all-remote-controls.co.uk/en/Sony/1066699-81366-replacement-remote-control-for-Sony-RMT-812-147595031.html