Mandis shop

Sony RMT-708

Original		Replacement		Original	Replacement
PLAY	Play	SLOW	Play / Slow		
START/STOP	Start/Stop		Power		
START/STOP	Start/Stop	REC MODE	Rec / Rec Mode		
REW	<<	TUNE-	<< / Tune-		
FF	>>	TUNE+	>> / Tune+		
STOP	Stop	HOLD	Stop / Hold		
	T	CH PAGE +	CH+ / Page+		
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze		
SLOW	I>/Slow		Right		
SLOW	I>/Slow	SHIFT + SLOW	Shift + Play /		
	W	CH PAGE -	CH- / Page-		
DISPLAY	Display	MEDIA DISPLAY	Display / Media		

https://all-remote-controls.co.uk/en/Sony/1068047-6337-replacement-remote-control-for-Sony-RMT-708-146757423.html