Mandis shop

# Sony RMT-708

| Original | Replacement |
|---|---|
| Play | Play / Slow |
| Start/Stop | Power |
| Start/Stop | Rec / Rec Mode |
| << | << / Tune- |
| >> | >> / Tune+ |
| Stop | Stop / Hold |
| T | CH+ / Page+ |
| Pause | Pause / Step / Freeze |
| I>/Slow | Right |
| I>/Slow | Shift + Play / |
| W | CH- / Page- |
| Display | Display / Media |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

https://all-remote-controls.co.uk/en/Sony/1068047-6337-replacement-remote-control-for-Sony-RMT-708-146757423.html