TELENET RC-RW100-DIGIBOX (SAT)

Original		Replacement	
	Power		Power
	TV - Gids	DISC NAV LIST	List
	Extra	SETTINGS OPT	Options
	Comm.	AD SUBT	Subt
	TV - Theek	SOUND DUAL	Dual
	Home	HOME SMART	Smart
	Mute	MUTE	Mute
	Help	DISPLAY INFO	Info
	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -
	CH+	+ CH	Ch +
	CH-	CH −	Ch -
	Up		Up
	Left		Left
	OK	OK	Ok
	Right		Right
	Down		Down

Original		Replacement	
	Delete	ECO 3D	3D
	Exit	CLEAR EXIT	Exit
	Back	RETURN BACK	Back
	<<		<<
	>>		>>
	Pause		Pause
	Play	PLAY MODE	Play
	Rec	REC MODE	Rec
	Stop		Stop
	Text	REPEAT TEXT	Text
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	1	1	1
	2	2	2
	3	3	3

Original		Replacement		Original	Replacement
4	4	4	4		
5	5	5	5		
6	6	6	6		
7	7	7	7		
8	8	8	8		
9	9	9	9		
0	0	0	0		
-/--	-/--	GUIDE	Guide		
	. ▯→	TIMER AV	AV		

Original		Replacement		Original	Replacement
	Power		Power		
	Mute	MUTE	Mute		
1	1	1	1		
2 abc	2	2	2		
3 def	3	3	3		
4 ghi	4	4	4		
5 jkl	5	5	5		
6 mno	6	6	6		
7 pqrs	7	7	7		
8 tuv	8	8	8		
9 wxyz	9	9	9		
0	0	0	0		
	. ▯→	TIMER AV	AV		
	Vol+	+ VOL	Vol +		
	Vol-	VOL −	Vol -		
	CH+	+ CH	Ch +		
	CH-	CH −	Ch -		