Mandis shop

Thomson CS520

Original		Replacement	
	On/Eco		Power
	Vol +	VOL +	Vol +
	Vol -	VOL –	Vol -
	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
	>>I		>>I
	I <<		I <<
RECORD	Record	REC MODE	Rec
DISC SKIP	Disc Skip	SETTINGS OPT	Options
CD	CD	1	1
EQ	EQ	2	2
TUNER	Tuner	3	3
B. BOOST	B. Boost	4	4
TAPE	Tape	5	5
OPEN-CLOSE	Open-Close	ZOOM	Eject
AUX	AUX	6	6

Original		Replacement	
	Repeat/RDS	REPEAT TEXT	Text
	PTY	-/-- GUIDE	Guide
	Sleep	PROG SLEEP	Sleep
	FM-ST	FAV PRE-CH	Pre Ch
	Intro/CT	OK	Ok
	Mute	MUTE	Mute
	Folder/Preset Up	+ CH	Ch +
	Folder/Preset	CH –	Ch -

https://al-remotecontrols.co.uk/Thomson/10524-184-replacement-remote-control-for-Thomson-CS520.html