| Original | | Replacement | |
|---|---|---|---|
| I/⏻ | Power | ⏻ | Power |
| OPEN/CLOSE | Open/Close | ZOOM ⏏ | Eject |
| REV ◀◀ | << | « | << |
| FWD ▶▶ | >> | » | >> |
| SKI ⏮ | I<< | ⏮ | I<< |
| KIP ⏭ | >>I | ⏭ | >>I |
| PAUSE/STEP | Pause/Step | ⏸ | Pause |
| STOP ■ | Stop | ■ | Stop |
| PLAY ▶ | Play | PLAY MODE ▶ | Play |
| TOP MENU | Top Menu | SHIFT + TOP MENU MENU | Shift + Menu |
| MENU | Menu | TOP MENU MENU | Menu |
| CLEAR | Clear | CLEAR EXIT | Exit |
| RETURN | Return | RETURN BACK | Back |
| ▲ | Up | ▲ | Up |
| ▼ | Down | ▼ | Down |
| ▶ | Right | ▶ | Right |
| ◀ | Left | ◀ | Left |

| Original | | Replacement | |
|---|---|---|---|
| ENTER | Enter | OK | Ok |
| ANGLE | Camera/Angle | A | Red |
| SUBTITLE | [...]/Subtitle | AD SUBT | Subt |
| AUDIO | O)))/Audio | SOUND DUAL | Dual |
| SETUP | Setup | SETTINGS OPT | Options |
| DISPLAY | Display | DISPLAY INFO | Info |
| ZOOM | Zoom | SHIFT + ZOOM ⏏ | Shift + Eject |
| SLOW I▶ | I>/Slow | PICTURE FORMAT | Format |
| E.A.M. | E.A.M. | E-MANUAL D.MENU | D. Menu |
| E.P.M. | E.P.M. | TIMER AV | AV |
| FL SELECT | F.L.Select | ECO 3D | 3D |
| FL DIM | F.L.Dim | C | Yellow |
| SEARCH T | T/Search | SEARCH TV/R | TV/R |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| 5 | 5 | 5 | 5 | | |
| 6 | 6 | 6 | 6 | | |
| 7 | 7 | 7 | 7 | | |
| 8 | 8 | 8 | 8 | | |
| 9 | 9 | 9 | 9 | | |
| 0 | 0 | 0 | 0 | | |
| +10 | +10 | GUIDE | Guide | | |
| RANDOM | Random | MEDIA | Media | | |
| MEMORY | Memory | D | Blue | | |
| REPEAT | Repeat | TEXT | Text | | |
| A-B RPT | A-B RPT | B | Green | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |