Mandis shop

REMCON1968

Original	Replacement	Original	Replacement
Power	Power		
Mute	Mute / Dimmer		
<<	<< / Tune-		
Play	Play / Slow		
Pause	Pause / Step / Freeze		
>>	>> / Tune+		
Up	Up		
Left	Left		
OK	OK		
Right	Right		
Down	Down		
Back	Back / Return		
=	Menu / Home		
Input	AV / Input / RDS		
Vol-	Vol-		
Vol+	Vol+		

https://all-remote-controls.co.uk/en/UNKNOWN/1066237-96293-replacement-remote-control-for-UNKNOWN-REMCON1968.html