Mandis shop

REMCON2108

Original		Replacement	
	Power		Power
	Source	RDS AV INPUT	AV / Input / RDS
SLEEP SNOOZE DIMMER	Snooze/Dimmer/S	LIST SMART	Smart / List
ON/OFF	Light On/Off	OK	OK
	Light-		Left
	Light+		Right
MOOD LIGHT ON/OFF	Mood Light On/Off		Up
MOOD LIGHT	Mood Light		Down
	Sound	TITLE SOUND	Sound / Title
C/F	C/F	MEDIA DISPLAY	Display / Media
	Vol+	+ VOL	Vol+
	[+]	-/-- GUIDE EPG	Guide / EPG / -/--
	<</Recall	TUNE-	<< / Tune-
MEM/M+	MEM/M+	PROGRAM TV/ RADIO	TV/Radio /
DST/NAP	>>/DST/NAP	TUNE+	>> / Tune+
	(1)	TV 1	1
	Vol-	VOL −	Vol-

Original		Replacement	
	(2)	DVD 2	2

https://all-remote-controls.co.uk/en/UNKNOWN/1067013-96810-replacement-remote-control-for-UNKNOWN-REMCON2108.html