Mandis shop

Woxter ANDROID TV700

Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
Browse	Browse	APP MEDIA	Media
	<X]	FAV PRE-CH	Pre Ch
	Home	HOME SMART	Smart
	Back	RETURN BACK	Back
	Mute	MUTE	Mute
	Vol +	+ VOL	Vol +

Original		Replacement	
	Vol -	VOL –	Vol -
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	[≡]	REPEAT TEXT	Text
	↖	CLEAR EXIT	Exit
OK	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Mute Tv	SHIFT + MUTE	Shift + Mute
	Vol - Tv	SHIFT +	Shift + Left
	Vol + Tv	SHIFT +	Shift + Right
	Power Tv	SHIFT +	Shift + Power

https://al-remotecontrols.co.uk/Woxter/1305793-replacement-remote-control-for-Woxter-Android-TV-700.htm