Mandis shop

WOX002

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Mute | | Mute / Dimmer |
| | Shuffle | | Blue / Prime Video / Random |
| | [/] | | >>I / Preset+ |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | 0 | | 0 |
| | Up | | Up |
| | Down | | Down |
| | Left | | Left |

| Original | | Replacement | |
|---|---|---|---|
| | Right | | Right |
| OK | OK | OK | OK |
| ESC | Esc | | Exit / Cancel / Clear |
| SNAP SHOT | Snap Shot | | Smart / List |
| CH | CH+ | | CH+ / Page+ |
| CH | CH- | | CH- / Page- |
| VOL | Vol+ | | Vol+ |
| VOL | Vol- | | Vol- |
| | Pause/Step | | Pause / Step / Freeze |
| RECORD | Record | | Rec / Rec Mode |
| STOP | Stop | | Stop / Hold |

https://all-remote-controls.co.uk/en/Woxter/1066601-82064-replacement-remote-control-for-Woxter-WOX002.html