Original		Replacement	
SYSTEM POWER	System Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
MUSIC 2	Music	TITLE SOUND	Sound / Title
STEREO 1	Stereo	LANG I/II AUDIO	Audio / Lang I/II
NIGHT +10	Night	EQ SUBTITLE	Subtitle / EQ
ENTERTAIN 3	Entertain	SURROUND	Eject / Surround
STRAIGHT ENT. EFFECT	Straight / Effect	FORMAT PICTURE	Picture / Format
LEVEL TITLE	Level	SIZE ZOOM	Zoom / Size
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
MOVIE 4	Movie	PROGRAM TV/RADIO	TV/Radio /
SET MENU MENU	Set Menu	HOME MENU	Menu / Home
PRESET/CH	Up		Up
A/B/C/D/E	A/B/C/D/E	ANGLE INFO	Info / Angle
	Left		Left
ENTER	Select	OK	OK
	Right		Right
	Down		Down

Original		Replacement	
VOLUME +	Volume+	VOL +	Vol+
PRESET/CH	Preset/CH+	CH PAGE +	CH+ / Page+
VOLUME –	Volume-	VOL –	Vol-
	Preset/CH-	CH PAGE –	CH- / Page-
STEREO 1	1	TV 1	1
MUSIC 2	2	DVD 2	2
ENTERTAIN 3	3	CD-STB 3	3
MOVIE 4	4	VIDEO 4	4
STANDARD 5	5	TAPE 5	5
SELECT 6	6	TUNER 6	6
EXTD SUR. 7	7	AUX-HDD 7	7
DIRECT ST. 8	8	USB 8	8
MULTI CH IN	Multi CH In	BLUETOOTH 9	9
STANDBY	Standby	SHIFT +	Shift + Power
DTV/CBL	DTV/CBL	SHIFT + TV 1	Shift + 1
DVD	DVD	SHIFT + DVD 2	Shift + 2
CD	CD	SHIFT + CD-STB 3	Shift + 3

Original		Replacement	Original	Replacement
VCR	VCR	SHIFT + VIDEO 4 Shift + 4		
TUNER	TUNER	SHIFT + TUNER 6 Shift + 6		
V-AUX	V-AUX	SHIFT + AUX - HDD 7 Shift + 7		
MD/CD-R	MD / CD-R	SHIFT + BLUETOOTH 9 Shift + 9		