Original	Replacement	Original	Replacement
Standby	SHIFT + Power	Volume-	VOL –
Power	Power	Mute	MUTE
Sleep	TIMER SLEEP	Title/Level	LEVEL TITLE
Phono	SHIFT + PC FAV MARKER	Up / Preset/CH+	▲
Tuner	SHIFT + TUNER 6	Menu/Set Menu	SET MENU MENU
CD	SHIFT + CD-STB 3	Pure Direct	PURE DIRECT
Multi CH In	PC FAV MARKER	Left / A/B/C/D/E	◄
V-AUX	SHIFT + AUX-HDD 7	Enter	ENTER
CBL/SAT	SHIFT + HDMI-SAT 0	Right /	►
MD/TAPE	SHIFT + TAPE 5	Night	NIGHT AUDIO
CD-R	SHIFT + BLUETOOTH 9	Audio	NIGHT AUDIO
DTV	SHIFT + TV 1	Return	TEST RETURN
VCR 1	SHIFT + VIDEO 4	Down / Preset/CH-	▼
DVR	SHIFT + USB 8	Display	ON SCREEN DISPLAY
VCR 2	SHIFT + -/-- GUIDE EPG	Straight	STRAIGHT EFFECT
DVD	SHIFT + DVD 2	STEREO	STEREO 1
Volume+	+ VOL	HALL	HALL 2

Original	Replacement
VOL –	VOL –
MUTE	DIMMER MUTE
TITLE	SOUND
▲	▲
MENU	HOME MENU
FORMAT PICTURE	FORMAT PICTURE
◄	◄
OK	OK
►	►
SHIFT + TIMER SLEEP	Shift + Sleep / Timer
AUDIO	LANG I/II AUDIO
RETURN BACK	RETURN BACK
▼	▼
MEDIA DISPLAY	MEDIA DISPLAY
SIZE ZOOM	SIZE ZOOM
TV 1	TV 1
DVD 2	DVD 2

Original		Replacement		Original		Replacement	
JAZZ 3	JAZZ	CD-STB 3	3				
ROCK 4	ROCK	VIDEO 4	4				
ENTERTAIN 5	ENTERTAIN	TAPE 5	5				
MUSIC 6	MUSIC	TUNER 6	6				
TV THTR 7	TV THTR	AUX-HDD 7	7				
MOVIE 8	MOVIE	USB 8	8				
THX 9	THX	BLUETOOTH 9	9				
EXTD SUR. ENT.	Extd. Sur.	SURROUND	Eject / Surround				
FREQ/RDS	<<I/ Freq/RDS	TUNE-	<< / Tune-				
EON	>>I/ Eon	TUNE+	>> / Tune+				
MODE – PTY	I<<I/ Mode PTY	PRESET-	I<< / Preset-				
SEEK – START	>>I / PTY Seek	PRESET+	>>I / Preset+				

Original		Replacement	
SYSTEM POWER	Power		Power
PRESET + CH	Preset Up	PRESET+	>>I / Preset +
PRESET + CH	Preset Up	+ CH PAGE	CH+ / Page+
+ VOL	Vol +	+ VOL	Vol +
CH − A/B/C/D/E	Preset Down	PRESET-	I << / Preset -
CH − A/B/C/D/E	Preset Down	CH PAGE −	CH- / Page-
VOL −	Vol -	VOL −	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
◄	Left A/B/C/D/E	◄	Left
ENTER	Enter	OK	OK
►	Right A/B/C/D/	►	Right
ON SCREEN DISPLAY	Display	MEDIA DISPLAY	Display / Media
STEREO 1	1	TV 1	1
HALL 2	2	DVD 2	2
JAZZ 3	3	CD - STB 3	3
ROCK 4	4	VIDEO 4	4
ENTERTAIN 5	5	TAPE 5	5

Original		Replacement	
MUSIC 6	6	TUNER 6	6
TV THTR 7	7	AUX - HDD 7	7
MOVIE 8	8	USB 8	8
THX 9	9	BLUETOOTH 9	9
STANDARD 0	0	HDMI - SAT 0	0
EXTD SUR. ENT.	ENT	PC FAV MARKER	Fav / Marker / PC
FREQ/RDS ◄◄	Freq/RDS	RDS AV INPUT	AV / Input / RDS
EON ►►	Eon	TOP MENU D.MENU	D.Menu / Top
MODE – PTY S ⏮	Mode PTY Seek	GOTO TEXT	Text / Goto
Y SEEK – START ⏭	PTY Seek Start	OPT-TOOLS SETUP	Setup / OPT /

Original		Replacement	
POWER AV	Power		Power
+ VOL	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
LEVEL TITLE	Title	TITLE SOUND	Sound / Title
▲	Up	▲	Up
SET MENU MENU	Menu	HOME MENU	Menu / Home
◀	Left	◀	Left
ENTER	Enter	OK	OK
▶	Right	▶	Right
NIGHT AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
TEST RETURN	Return	RETURN BACK	Back / Return
▼	Down	▼	Down
ON SCREEN DISPLAY	Display	MEDIA DISPLAY	Display / Media
STEREO 1	1	TV 1	1
HALL 2	2	DVD 2	2
JAZZ 3	3	CD - STB 3	3

Original		Replacement	
ROCK 4	4	VIDEO 4	4
ENTERTAIN 5	5	TAPE 5	5
MUSIC 6	6	TUNER 6	6
TV THTR 7	7	AUX - HDD 7	7
MOVIE 8	8	USB 8	8
THX 9	9	BLUETOOTH 9	9
STANDARD 0	0	HDMI - SAT 0	0
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
EXTD SUR. ENT.	ENT	PC FAV MARKER	Fav / Marker / PC
FREQ/RDS ◀◀	<<	TUNE- ◀◀	<< / Tune-
EON ▶▶	>>	TUNE+ ▶▶	>> / Tune+
MODE – PTY S ⏮	I <<	PRESET- ⏮	I << / Preset-
Y SEEK – START ⏭	>>I	PRESET+ ⏭	>>I / Preset+
REC DISC SKIP	Rec	REC MODE	Rec / Rec Mode
■	Stop	HOLD ■	Stop / Hold
❚❚	Pause	STEP - FREEZE ❚❚	Pause / Step / Freeze
▶	Play	SLOW ▶	Play / Slow