Original	Replacement	Original	Replacement
DIMMER Dimmer	SHIFT + DIMMER MUTE Shift + Mute / Dimmer	MEMORY Memory	REC MODE Rec / Rec Mode
SLEEP Sleep	TIMER SLEEP Sleep / Timer	PRESET < Preset	CH PAGE – CH- / Page-
Power	Power	PRESET < Preset	SHIFT + PRESET- Shift + I<< / Preset-
A SPEAKERS Speakers A	TITLE SOUND Sound / Title	PRESET Preset >	+ CH PAGE CH+ / Page+
B SPEAKERS Speakers B	LANG I/II AUDIO Audio / Lang I/II	PRESET Preset >	SHIFT + PRESET+ Shift + >>I / Preset+
OPTICAL Optical	TV 1 1	CLEAR Clear	CLEAR EXIT CANCEL Exit / Cancel / Clear
COAXIAL Coaxial	DVD 2 2	MODE Mode	FORMAT PICTURE Picture / Format
CD CD	CD - STB 3 3	DISPLAY Display	MEDIA DISPLAY Display / Media
LINE 1 Line 1	VIDEO 4 4	Up	Up
LINE 2 Line 2	TAPE 5 5	Left	Left
PHONO Phono	AUX - HDD 7 7	ENTER Enter	OK OK
TUNER Tuner	TUNER 6 6	Right	Right
NET Net	USB 8 8	Down	Down
BLUETOOTH Bluetooth	BLUETOOTH 9 9	HOME Home	HOME MENU Menu / Home
BAND Band	LIST SMART Smart / List	RETURN Return	RETURN BACK Back / Return
TUNING << Tuning	SHIFT + TUNE- Shift + << /	SETUP Setup	OPT-TOOLS SETUP Setup / OPT /
TUNING Tuning >>	SHIFT + TUNE+ Shift + >> / Tune+	VOLUME Volume+	+ VOL Vol+

Original		Replacement		Original	Replacement
OPTION	Option	SHIFT + SETUP (OPT-TOOLS)	Shift + Setup / OPT / Tools		
NOW PLAYING	Now Playing	GUIDE EPG (-/--)	Guide / EPG / -/--		
VOLUME	Volume-	VOL –	Vol-		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat		
▷/DD	Play	SLOW ▶	Play / Slow		
▷/DD	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze		
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random		
⏮/◀◀	I<<</<<	TUNE- ◀◀	<< / Tune-		
⏮/◀◀	I<<</<<	PRESET- ⏮	I<< / Preset-		
▭	Stop	HOLD ■	Stop / Hold		
▷▷/⏭	>>/>>I	TUNE+ ▶▶	>> / Tune+		
▷▷/⏭	>>/>>I	PRESET+ ⏭	>>I / Preset+		