Original		Replacement	
POWER	POWER	Power	Power
SLEEP	SLEEP	TIMER SLEEP	Sleep / Timer
6CH INPUT	6 CH. INPUT	RDS AV INPUT	AV / Input / RDS
DVD	DVD	SHIFT + DVD 2	Shift + 2
D-TV/CBL	D-TV / CBL	DVD 2	2
VCR	VCR	VIDEO 4	4
V-AUX	V-AUX	AUX - HDD 7	7
CD	CD	CD - STB 3	3
TUNER	TUNER	TUNER 6	6
MD/CD-R	MD / CD-R	BLUETOOTH 9	9
– PRES	TUNER – PRESET-	CH PAGE –	CH- / Page-
ESET +	TUNER – PRESET+	+ CH PAGE	CH+ / Page+
A/B/C/D/E	TUNER – A	NETFLIX SEARCH	Red / Netflix / Search
A/B/C/D/E	TUNER – B	APP REPEAT	Green / APP / Repeat
A/B/C/D/E	TUNER – C	YouTube REPEAT A-B	Yellow / YouTube / Repeat
A/B/C/D/E	TUNER – D	Prime Video RANDOM	Blue / Prime Video / Random
A/B/C/D/E	TUNER – E	OPT-TOOLS SETUP	Setup / OPT / Tools

Original		Replacement	
HALL	HALL	HDMI - SAT 0	0
JAZZ CLUB	JAZZ CLUB	TV 1	1
ROCK CONCERT	ROCK CONCERT	TITLE SOUND	Sound / Title
ENTER-TAINMENT	ENTERTAINMEN	LIST SMART	Smart / List
TV SPORTS	TV SPORTS	SHIFT + TV 1	Shift + 1
MONO MOVIE	MONO / MOVIE	FORMAT PICTURE	Picture / Format
MOV 1– THEAT	MOVIE THEATER –	TAPE 5	5
OVIE EATER–2	MOVIE THEATER –	USB 8	8
DD/DTS SUR.	DOLBY / DST SUR.	SURROUND ⏏	Eject / Surround
MATRIX 6.1	MATRIX 6.1	-/-- GUIDE EPG	Guide / EPG / -/--
SELECT	SELECT	OK	OK
LEVEL	LEVEL	MEDIA DISPLAY	Display / Media
^	UP	▲	Up
SET MENU	SET MENU	HOME MENU	Menu / Home
–	-	◀	Left
+	+	▶	Right
TEST	TEST	GOTO TEXT	Text / Goto

Original		Replacement	
	DOWN		Down
STEREO EFFECT	STEREO /	LANG I/II AUDIO	Audio / Lang I/II
MUTE	MUTE	DIMMER MUTE	Mute / Dimmer
	VOLUME+	+ VOL	Vol+
VOLUME	VOLUME-	VOL −	Vol-

Original	Replacement